



StarStyler™

BRAIDER

INSTRUCTIONS




ASSEMBLY
Snap **hoofclip** into place from underneath the stand.

TO TWIRL TAIL HAIR

1 Place the horse's hooves into the **foot holes** in the stand.

2 Take a small strand of hair from the tail and smooth it out. Put the extra hair into the **left storage slot** in the stand. Clip the end of the small strand of hair into the **styler clip**, leaving about **1"** of hair out. Hold the **StarStyler** away from the horse and crank the handle in the direction of the **single arrow** about five to six complete turns.




Kenner®


©Kenner 1989 a division of Tonka Corporation

3632016000


ATTENTION PARENTS!
Some children may require parental help in operating this toy for the first time.




- 3 While holding the twirled hair, unclip the hair and put it in the **right storage slot** in the stand. Take some more hair—about the same amount as before, and smooth it out. Clip the hair into the styler as before. Hold the Styler away from the horse and crank the handle in the direction of the **single arrow** about five to six complete turns.




- 4 Leave the second lock of hair in the **styler clip**. Take the twirled hair from the **right storage slot** on the stand and place it in the other clip of the styler. Now, turn the handle the opposite way—in the direction of the **two arrows** about five to six complete turns.




- 5 While holding the two pieces of twirled hair together, slide the hair out of the clips or open the **styler clips**. Put the twirled hair in the rubber band loop of the barrette (as shown). While holding the barrette, pull the other loop until the hair is securely fastened.




- 6 Place the completed twirled tail around the right rear leg. Go back to No. 2 to repeat the process to twirl more hair.




- TO TWIRL MANE HAIR**
- 7 Flip the mane over onto the other side of the horse away from you. Take a small strand of hair from the mane and smooth it out. Attach the small strand of hair into the **styler clip**, leaving about **1"** of hair out. Hold the styler away from the horse and crank the handle in the direction of the **single arrow** about five to six complete turns.




- 8 While holding the twirled hair, open the clip and put the hair into the **side storage slot** in the stand. Take some more hair, (about the same amount as before), next to the piece you took before, and smooth it out. Attach the hair, as before, into the **styler clip**. Hold the styler away from the horse and turn the handle in the direction of the **single arrow** again.



- 9 Leave the second lock of hair in the styler clip and take the hair from the **side storage slot**, placing it in the other **styler clip**. Now, crank the handle the opposite way, in the direction of the **two arrows** about six complete turns.



- 10 While holding the two pieces of twirled hair together, slide the hair out of the clips or open the **styler clips**. Put the twirled hair in the rubber band loop of the barrette (as shown). While holding the barrette, pull the other loop until the hair is securely fastened.



- 11 Place the completed twirl on the opposite side with the rest of the mane. Go back to No. 7 and repeat the process to twirl another strand of hair.

WE REALLY DO CARE!

We make each toy with tender loving care. If there is a problem with your toy as you receive it, please let us know. Simply describe the problem and mail that description along with your name and address to:

KENNER PRODUCTS
 Consumer Affairs Dept., 1014 Vine St.,
 Cincinnati, Ohio 45202